

How to operate the Margarita Machine

Follow these steps for an easy set up:

1. Confirm that feet of acrylic bowls are seated in place. (this will prevent the mix from spilling)
2. Combine ingredients in a separate container (a bucket) using one of the recipes provided. Remember each bowl can work independently.
3. Pour mix in acrylic bowls. DO NOT FILL OVER THE MAX LINE. Remember, water expands when it freezes and you may have an over flow.
4. Place the Cover Lids on top of the acrylic bowls and plug in the back of the machine.
5. Set the controls down to freeze. All switches should be down to the (*) snow sign. The green light (freezing indicator) below the switch panel should turn on within 5 min.
6. Turn on the augers switch. And wait!

Other Helpful Guide Lines:

- Avoid direct sunlight and ambient temperature over 80* F.
- Provide 10” space for ventilation on both sides of machine.
- DO NOT add any solids. (NO ICE, FRUITS, ETC.)
- Do not operate unattended or empty. It can damage the machine.
- ALLOW 2 HOURS TO FREEZE!!

Trouble Shooting:

- ✓ Power to machine (cord and plug)
- ✓ Acrylic bowls not seated level.
- ✓ Automatic Defrost Timer:
 - Make sure the LEFT switch is positioned on “0” and the RIGHT switch is positioned on “RUN”, press the reset button (“R”) with ball pen.
- ✓ Use recommended mixes.

