

# How to operate the Popcorn Machine

---

## There are three switches on the popper.

- LIGHT & WARMER SWITCH: Turns on the heat to the bottom heat and heat light.
- THE KETTLE MOTOR SWITCH: Turns on the motor which drives the kettle agitator shaft.
- THE KETTLE HEAT SWITCH: Turns on the heat element.

## Popping Instructions

1. Confirm that feet are seated in place on a flat surface.
2. Turn Kettle Heat, Light Warmer, and Kettle Motor switch to “ON”
3. Load PRE-MEASURED popcorn kit into Kettle (first load takes about 5min to pop)
4. When corn has popped, Dump Kettle!
5. Repeat Cycle starting with #3; (Always pop 3-5 batches for best popcorn.)
6. When done popping turn kettle motor and heat switch to “OFF” and leave the light & warmer switch “ON”
7. Keep popper door open when popping.

**WARNING!!!! TO AVOID SERIOUS BURNS DO NOT TOUCH THE KETTLE WHILE IT IS HOT!**